









Notes:

- 1. See drawing 1101 **Bearing and T-Nut Detail** for dimensions
- 2. The T-Nut holes are only drilled on the side that will hold the stepper motor.
- 3. The bearing hole is drilled on both sides be sure the recess for the bearing is on the **outside**.
- 4. This rabbet is 1/8" [2.82mm] deep

Project					
DIY CNC Router					
Title					
X-Axis Sides					
Size	Dwg No		ate		Rev
Α	1011		12/22/17		00
	HobbyCNC	Scale 1:5		Sheet 3 of 3	3